

## 3D BRACELET JIG TEMPLATE

### Medium Geometric Bangle Bracelet

**Materials: 35 inches of 16 or 14Ga German Style or Artistic Wire**

Set 44 pins into the 3D Bracelet Jig as shown following the guide. Begin by placing one end of the wire into hole G1, then carefully bend the wire to a 90 degree angle around peg D2 and across to D4, then bend the wire above F4 and across to F6 and continue until the pattern is completed. Remove the pins and the wire form.

Carefully cut the end wires to meet and use an Artistic Wire Crimp Tube to finish. Close the angles to make the bangle smaller, open angles to make bangle larger.



Wire beads into the areas of the Bangle Bracelet that are not touching, or wire onto the tops of the curves as you are using the Jig.

Artistic Wire®

**Beadalon®**

