

DESIGN WORKSHOP

ELASTICITY CHAIN BRACELET INSTRUCTIONS

By: Meredith Roddy



Materials

- 340N-208 ELAST CHAIN SHORT SC 4FT
- 340N-220 ELAST CHAIN SHORT BLK 4FT
- 326B-414 QK LINKS CONNECT MD SP 60PCS
- A314-20S-10-05 20G CHNML RND 9/64" TRS 90P
- (30) 6mm top drilled rivoli pendants (not included)

TOOLS:

- 211A-002 BEADING SCISSORS DESIGNER
- 201A-101 SPARKLE CHAIN NOSE PLIERS
- 201A-103 SPARKLE CHAIN NOSE BENT PLIERS

1. Cut (2) strips of elasticity chain 7.5" each.

2. Beginning at the 5th hole from the end, use the QuickLinks Connectors to connect the two strips of Elasticity Chain together. Take care that the closed parts of the QuickLinks are all facing the same direction.

3. You should have 4 open holes on each side. If one side is longer, trim to length.

4. Attach the linked chain into a circle with two QuickLinks Connectors on each end.

5. Use the Jump Rings to attach the Rivoli Pendants to the middle hole between the connectors on both sides.

6. Wear and enjoy!